WARNING: Validate the kit contents with the component list included on this page before proceeding. This kit is intended to be used in a modified vehicle. Please read this page thoroughly and be sure that you understand everything explained on it prior to opening any of the enclosed packages, or before attempting to install any of the components. Once this kit has been opened or a component installed, the kit is not returnable.

This kit contains the following components:

Pag	Part	Description	Quantity
<u>Bag</u>	<u>Number</u>	Description	<u>Quantity</u>
G	510839	Dash Harness kit	1
Н	510840	Instrument Cluster wiring kit	1
J	510841	Engine Wiring Kit	1
L	510842	Front Light wiring kit	1
Μ	510843	Rear Body Wiring kit	1
	510867	Fuse, Relay, and Flasher kit	1
	510476	Alternator and Main Power Conn. kit	1
	510730	VSS Lead Wires	1
	500919	Practice Terminal Crimping set	1
	500042	Dimmer Switch	1
	500332	Headlight Switch	1
	92973232	Firewall Mod Template	1


Validate the kit contents with this component list. If there are any discrepancies with incorrect or missing parts, stop your installation and notify the supplier you purchased the kit from before proceeding.

1. This kit IS NOT set up with a resistance wire for a standard points-type ignition system. It is wired with a full 12-volt primary ignition feed. See pages 20 through 22 for the various Ignition System Wiring configurations.

2. This kit includes the wiring to support the use of a factory heater system and/or aftermarket heater and A/C systems. This kit also includes the main power feed and the compressor extension wires that will support the use of the factory original A/C system, but DOES NOT include any of the other factory A/C wiring.

3. This kit only supports the use of a higher current, self-exciting 1-wire alternator or GM SI type internally regulated alternator. Optional adapters may be necessary for certain applications.

4. AAW DOES NOT support the use of the factory ammeter. We recommend the use of a voltmeter to monitor your charging system.







www.americanautowire.com 856-933-0801

#### 510838 - Classic Update Series Kit 1971-80 IH Scout

**510838 1971-80 IH Scout** Instructions Classic Update Series

> © COPYRIGHT 2004 American Autowire / Factory-Fit Used with express permission of nerican Autowire / Factory-Fit

92973231 Rev 1.0

10/14/2024

# **START HERE !**

#### PLEASE READ THIS BEFORE STARTING INSTALLATION !

This wiring kit is designed for ease of installation. Please read the guidelines below BEFORE STARTING installation to guarantee a successful job. Use an appropriate crimping tool, which folds the wings of the open barrel terminals down into the wire, as shown on this page. If you use our crimping tools and correctly crimp the included terminals, soldering is not necessary. If you are unsure about a particular crimp, soldering is recommended. Our factory crimped terminations are installed by GM approved five ton presses, and soldering these terminations is not necessary.



AAW offers a great terminal crimping video entitled "Proper Crimping Video". It can be viewed by visiting YouTube.

Type the following address into your web browser, to go directly to the video: www.youtube.com/watch?v=JAgEDoVI-co

Youtube Channel: www.youtube.com/user/WiringHarness







37796 SI to CS Alternator Adapter 500479 40 Amp

The terminals that we supply in our kits, utilize what is known as an F crimp. The F crimp, in a cross section, will look like the illustration below, when done correctly.





end view of un-crimped terminal

We carry the following crimping hand tools, to help with your terminal crimping. These hand tools are available, for purchase or rental.

p/n 510585 OEM small gauge terminal crimping tool




merican Autowire

If you have any questions concerning this or any of our products, please feel free to call us at 1-856-933-0801.

Page 2

www.americanautowire.com 856-933-0801







510226 LED Electronic flasher

wire core

proper crimp of terminal

#### p/n 510586

OEM large gauge terminal and double small gauge terminal crimping tool



<u>Bags</u> :	Pages:	Sections:						
	4-5	Fuse, Circuit Breaker, Relay and Flasher (5	10867) Placement, and Fuseblock/Bulkhe	ad installation				
G	6-14	Dash Harness (510839) (Installation) – This is the main harness in the kit and it should be installed first. It can be installe modified, firewall opening and routed behind the dash frame with the frame just as your original was. This harness connects						
		Accessory Power Feed connector Park Brake Switch Third Brake Light Feed LH & RH Courtesy Lights Horn Relay Fog Lamp Relays Headlamp Dimmer Switch Stop Light Switch Interior 12V and tach leads for ECU (if equipped) Headlight Switch Wiper Switch Factory A/C Feed A/C Compressor Feed	Cluster Connection for Temp. and Oil Gauges Cluster Connection for Gas Gauge Hazard Flasher Ignition Switch Turn Signal Switch Electric Speedo Ground Dash Light Candelabra (optional lamp use) Heater Panel Light Heater/Blower Motor Switch Cigar Lighter Speedo Cluster Connection Electric Speedometer Connection Fuel Pump Lead	Neutral Safety Switch Relay Radio Clock Feed Fog Lamp Switch Dash Grounds Blower Motor Wiper Motor Electric Speedometer Extension 12V Fused Battery Feed for Co 4WD Indicator Lamp and 4WD Illumination Lamp Feed for Co Back Up and Neutral Safety So				
Н	15-18	<u>Gauge Cluster Harness (510840)</u> – This harn	less is assembled by the customer and conr	nects to:				
		Printed Circuit Boards (PCB)	Dash Harness					
	18	Aftermarket Gauges:						
		All gauges (Volts, Fuel, Speedo, Oil, Temp, Tach)						
J	19-23	Engine Harness (510841) – This harness connects to the Dash harness and the:						
		SI Alternator Connections Electric Choke The Assembled Mega Fuses	Ignition System Starter Solenoid Engine Temperature Sender	Tachometer Signal Oil Pressure Sender A/C Compressor Lead				
L	24-25	Front Light Harness (510842) - This harness	connects to the Dash harness and the:					
		LH & RH Headlights LH & RH Parking/Turn Lamps Brake Warning Switch	LH & RH Side Markers Washer Pump/Reservoir Electric Fan Trigger Feed	Fog Lamps Horns				
М	26-29	Rear Body Harness (510843) - Interior and exterior connections. This harness connects to the Dash harness and the:						
		B/U, Stop/Tail, Rear Running Lamp Leads Tail Lamp Connections and Grounds 78-80 Tail Light Extensions (Stop/Tail, B/U, Side Mkr.)	71-77 Side Marker extensions Fuel Tank Lead Fuel Tank Sender and Ground Extension	Dome Light Wires				

ed directly into the original, or ts to:

sion Console /D Switch Console Switch Connections

Fuel Pump Lead




www.americanautowire.com 856-933-0801

## **1971-80 IH Scout 510838** Classic Update Series 92973231 Rev 1.0 10/14/2024

# **Fuse Block and Bulkhead installation instructions:**

NOTE: Prior to installing the Dash harness into the vehicle, obtain the Fuse, Flasher, and Relay Kit, **510867**, and plug all of the fuses and turn signal flasher into the Fuse Block (see below). Also, plug the Horn Relay and Fog Lamp Relays into the relay bases, and the hazard flasher into its connector (see page 7) on the dash harness.





Page 4

Fuse usage details. NOTE: Head lights are protected by the H/L switch internal 25A breaker

<u>Fuse</u>	<u>e usage details. No</u>	<u> </u>	ights are prote
Fuse #	Fuse Block Printing	Fuse Rating	
1	DASH LTS	10A	Cluster lights, Tac Light, Optional das
2	FUEL	20A	Electric fuel pump,
3	BRK/CTSY	15A	Stop and third bral Fog light relay coil
4	BAT 2	30A	B+ Feed for any o
5	GAUGES	10A	Gauges (Temp, Fu 4x4 Light, Back-u
6	FAN	30A	Electric fan
7	CLOCK	10A	Battery feed for clo
8	WIPER	15A	Wiper motor, Fror
9	AC/HEAT	30A	Main Heater or A/0
10	LIGHTER	20A	Cigar Lighter, Optic
11	BAT 1	20A	B+ Feed for any o
12	IGN 1	10A	Electric choke
13	ACCY 1	30A	Feed for any optio
14	HAZARD	15A	Hazard lights
15	PWR WDO	30A	Ignition Feed for o
16	RADIO	10A	Accessory feed "or
17	FOG LT	20A	Fog lamp feed
18	TURN	10A	Turn signal
	Hazaro flasher from 510867	r	Fog (bo
	Hazard flas connector f page 7	from	

#### System Wiring Protected

chometer lights, Speedometer lights, Heater Control Panel ash lights plugged into candelabra

o, Ignition feed for electric speedo (Accy 6-way conn).

ake lights, under dash courtesy lights, dome light, hood light, il, Rear running lights, Front park lights.

optional battery powered feed. (Accy 6-way conn)

Fuel, Oil Pressure and Voltmeter). B+ for options as tachometer up Lights, Brake Warning Light

lock, radio battery feed

nt windshield washer pump

/C Feed Switch


ion battery fused feed to console area.

optional battery powered feed. (Accy 6-way conn)

onal accessory powered feed. (Accy 6-way conn).

options such as power windows (Accy 6-way connector)

on-off" for the radio



## Fuse Block and Bulkhead installation instructions:

#### **STEP 1: DISCONNECT YOUR BATTERY**

Disconnect the battery before installing the wiring kit. This is to prevent any accidental shorting caused by bare wire ends.

#### **STEP 2: LOAD THE FUSE BLOCK**

Prior to installing the dash harness to the dash, obtain the Fuse, Flasher, and Relay Kit 510867 and plug all of the fuses and turn signal flasher into the fuse block. Also, plug the horn relay, fog lamp relays, and hazard flasher into the dash harness. (See page 4)

#### **STEP 3: PREPARING TO INSTALL THE DASH HARNESS**


The Dash Harness routing will be the same as the original factory Instrument Panel Wiring Harness routing. Be sure to duplicate this routing.

#### **STEP 4: START INSTALLING THE KIT**

This kit is divided into individual sections that are identified by a letter printed on the sheets enclosed in each bag. The items covered, the order of installation, and the pages with their detailed installation instructions are shown on page 3.

#### **Fuse Block and Bulkhead Attachment**

Locate the original factory fuse block/bulkead opening in the upper LH corner of the firewall from the inside (From the outside, upper RH corner). If your truck is a 78 to 80 model, no modification is required as the fusebox and bulkhead will install directly in the factory firewall opening. If your truck is a 71-77 model, it will be necessary to use the 92973232 Template included in this kit to modify the opening in your firewall, and to drill two new mounting holes. Attach the fuse block and bulkhead assembly to the firewall using the self tapping screws "L" found on page 6. (See figure A below for details)




stock, or new mounting hole




www.americanautowire.com 856-933-0801



Below are the supplied misc. terminals, connector bodies and assorted components included in the 510839 Dash Harness and Loose Piece bags. These will be used to complete your Dash Harness connections and are referred by the letters and descriptions below from this point forward.





(56 series small gauge male terminal, 5 pcs.)

(56 series large gauge male terminal, 2 pcs.)

(Female pin terminal, 3 pcs)

(large rubber sleeve, 2 pcs)




www.americanautowire.com 856-933-0801

#### 1971-80 IH Scout 510838

Classic Update Series

92973231 Rev 1.0 10/14/2024






Page 7

and lead to the floor in the stock location)




#### Underdash courtesy lamp and doorjamb switch instructions:




# Use the provided 6-way empty connector, which is attached to the 6-way Accessory connector on the Dash Harness, and terminals "M" and "N" (see Parts Kit 9297323 to add power wires for the following optional systems

<u>Wire</u> <u>Color</u> Tan Orang Red Pink	Wire Printing FUEL PUMP 12V BATTERY FUSED (no printing) 12V IGNITION FEED	Fuse Block Printing FUEL BAT2 BAT1 PWO WDO	<u>Fuse</u> <u>Rating</u> 20A 30A 20A 25A	<b>Description</b> Fused 12 volt IGNITION feed for an electric fuel pump (may also be used to feed power to another igniti Fused 12 volt BATTERY feed (may also be used to feed power to another battery circuit). Fused 12 volt BATTERY feed for power locks (may also be used to feed power to another battery circuit Fused 12 volt IGNITION feed for power windows (may also be used to feed power to another ignition cir
Brown	IGNITION SW ACCY	ACCY1	30A	Fused 12 volt ACCY. feed (may also be used to feed power to another accessory circuit).

Page 8



d from inals "M" er wires arness 36)	www.americanautowire.com 856-933-0801
nition circuit). uit). circuit).	<b>1971-80 IH Scout</b> <b>510838</b> Classic Update Series 92973231 Rev 1.0 10/14/2024



2. Use "**Table B**" above to align the wires.

3. Note: The steering column horn button switches ground for the horn relay, which then switches power to the horns.



This diagram is to connect the AAW turn signal dash harness connection to a stock 1971-77 or some **aftermarket** steering columns. If you have a **stock** 1978-80 steering column, or a reproduction turn signal switch, the AAW Turn Signal switch connector will plug directly into it with no modifications needed.

# Required steering column connector modification for OEM and some aftermarket steering columns

#### <u>"Table B"</u>

#### Dash harness turn signal switch wires to aftermarket or stock 1971 - 80 turn signal switch


Wire g	Connector Cavity	<b>Original</b> <u>Wire Color</u>
SW Rear Turn ear Turn witch Feed W – Hazard Front Turn ont Turn Relay Ground	P N L K J H G F E D	Dark Green 70A Dark Green 57 Dark Green 56 Dark Green 55A Dark Green 60A Dark Green 57A,B Dark Green 56A,B Dark Green 85A None None None

# 1. Remove the **aftermarket or stock 1971-77** turn signal switch connector and replace it with the AAW 14-way connector "**S**" from page 6. Crimp terminal "**R**" onto each of the original turn signal switch wires, and plug them into connector "**S**" as shown at left. (see parts kit **92973236**).




#### VSS dash jumper connection to the 500730 VSS lead wire kit:

#### Electric Speedo VSS connection:



If you are using an aftermarket electric speedometer in your vehicle, you will need to connect the vehicle speed sensor (VSS) Lead Wires from the 510730 kit to the dash side connection of your dash harness. The yellow and solid purple wires must remain twisted together as shown above. These three wires will need to pass through the firewall or floor of your vehicle down to the vehicle speed sensor unit in the transmission. Generally, the solid purple wire connects to the "signal" lead, the yellow wire connects to the "ground" lead, and the purple/white stripe wire connects to the "12 volt power" lead on the vehicle speed sensor assembly. However, you should consult the directions that came with your gauges, and connect your vehicle speed sensor per the manufacturer's instructions.





www.americanautowire.com 856-933-080\*







Terminals V and N, connectors U and T (page 6)




12V ignition wire from ECU (not included)


Tach wire from ECU (not included)



Windshield wiper and washer switch connections:




NOTE: Listed below are the functions of each of the 5 wiper/washer wires: 1. The blue wire is the fused 12v power feed from the fuse box to the switch. 2. The green wire is the "park" feed from the switch to the wiper motor. 3. The black wire is the "high speed" feed from the switch to the wiper motor. 5. The red wire is the "low speed" feed from the switch to the wiper motor.





The wiper/washer switch wires (see page 7)





















www.americanautowire.com 856-933-0801



## 510840 Gauge Cluster harness installation instructions:




#### **GAS GAUGE AND AMMETER (NOT SUPPORTED) GAUGE CLUSTER, ALL YEARS**

# 510840 Gauge Cluster harness installation instructions:

#### **OIL PRESSURE AND TEMPERATURE GAUGE CLUSTER, ALL YEARS**



Helpful Hint: The new terminals N fit onto the factory circuitboard pins very tightly. After installing new terminals N into connector M as shown at the right, we recommend inserting either a pic or an awl into the open end of each terminal to open them up a slight bit. This will help the connector install onto the circuitboard easier.











#### SPEEDOMETER CLUSTER, **ALL YEARS**



## 510840 Gauge Cluster harness installation instructions:

FOLLOW THE MANUFACTURER'S INSTRUCTIONS FOR BEST RESULTS.






<u>(400)</u>	VSS Ground	Connect to VSS neg. "" on speedometer.
<u>(401)</u>	VSS Signal	Connect to VSS input on speedometer.
<u>White</u> (402)	VSS Power	Connect to 12V power on speedometer.
<u> White (151)</u>	Speedo Ground	Connect to ground on speedometer.



# 510841 Engine harness installation instructions:

Below are the supplied terminals, connector bodies, pigtail assemblies, and assorted components included in the 510841 Engine Harness and Loose Piece bags. These will be used to complete your Engine Harness connections as shown on page 20 trough 23, and are referenced by the letters and descriptions below.






www.americanautowire.com 856-933-0801





Classic Update Series

92973231 Rev 1.0 10/14/2024












www.americanautowire.com 856-933-0801




Note: Assemble the 510841 engine, 510842 front light, and 510843 rear body harnesses, then plug that assembly onto the firewall bulkhead connector. Route the engine wires to their respective locations/senders as shown at the left.


NOTE: An electronic distributor and Gold Box Ignition module are shown. The AAW pink "coil" lead needs to be connected to the black lead that mates with the red wire at the gold box connection, and to the "+" location on the coil. The black wire that mates with the brown wire at the gold box connection connects to the "-" location on the coil.



92973231 Rev 1.0 10/14/2024










www.americanautowire.com 856-933-0801




Note: Obtain the fuel pump wire "X" as found on pages 6 and 19 of this instruction set, plug it into the location shown at the left, then assemble the 510841 engine, 510842 front light, and 510843 rear body harnesses, and plug that assembly onto the firewall bulkhead connector. Route the other end to your fuel pump or fuel pump relay area, cut off the female terminal, and attach it to the pump or relay.



# 510842 Front Light installation instructions:

Below are the supplied terminals, connector bodies, pigtail assemblies, and assorted components included in the 510842 Front light Harness and Loose Piece bags. These will be used to complete your Front light Harness connections as shown on page 25, and are referened by the letters and descriptions below.




Page 24




www.americanautowire.com 856-933-0801







Below are the supplied terminals, connector bodies, pigtail assemblies, and assorted components included in the 510843 Rear Body Harness and Loose Piece bags. These will be used to complete your Rear Body Harness exterior and interior connections as shown on pages 27 through 29, and are referenced by the letters and descriptions below.



1971-77 rear body harness installation instructions:





Note: Assemble "N" (the 510843 rear body), the 510841 engine and 510842 front light harnesses, then plug that assembly onto the firewall bulkhead connector. Route item "P" harness over to the transmission tunnell area and down the driver side frame rail to the back of the truck.

Route the orange and white wires down the driver side frame rail, up through the floor into the cabin, then up to the dome lamp assembly.


Connect as shown below using the terminals, connectors and pigtails from page 26.



www.americanautowire.com 856-933-0801



**TRAVELER** rear body harness installation instructions:



Note: Assemble "N" (the 510843 rear body), the 510841 engine and 510842 front light harnesses, then plug that assembly onto the firewall bulkhead connector. Route item "P" harness over to the transmission tunnell area and down the driver side frame rail to the back of the truck.

Route the orange and white wires down the driver side frame rail, up through the floor into the cabin, then up to the dome lamp assembly.

Connect as shown below using the terminals, connectors and pigtails from page 26.



www.americanautowire.com 856-933-0801




92973231 Rev 1.0 10/14/2024

# 510838 finishing detail installation instructions:

Making your firewall electrical connection corrosion and weather resistant:

engine harness 20-way connector



assembly, ready to bolt

front light 10-way connector rear body 7-way connector

NOTE: We recommend the following once you have completed the installation of your underhood engine, forward lamp and rear body connections:


1. Remove the engine, front light and rear body connector assembly from the firewall and apply dielectric grease to the terminals as shown above. This will help with continuity and also prevent corrosion to any of the terminals.


2. Re-attach the engine, front light and rear body connector assembly to the firewall and apply silicone sealer to the back of the connectors as shown above. This will help seal the connector and keep water and moisture front going through to the inside of the vehicle via the bulkhead assembly.



www.americanautowire.com 856-933-0801







А

C (175 amp Megafuse) D (175 amp Megafuse) E (175 amp Megafuse) (1) (Megafuse jumper) E (1) (Alternator boot) F (1) (cut into six 1.0" pieces) Page 1

G

Н

J

Κ

1. One this page, you will find the wire, fuse bodies, fuses, boot, ring terminals, and shrink tubing (items A through K) that are necessary to connect your alternator and main power feed for your new AAW wiring kit. Please be sure that all of the necessary components are present before starting this portion of your installation. If anything is missing, stop what you are doing and contact AAW at the number listed below right away.


2. On page 2, you will find directions for building the 2 Megafuse assemblies (items B,C and D) into one unit.

3. On page 3, you will find an overall concept of how to connect the Megafuse assemblies to your starter solenoid, alternator and main power feed of your new wiring system.

4. On page 4, you will find tips on building your charging circuit wires and assembling them and the main panel power feed wire to the Megafuse assembles.



(1)



#### Assembling the (2) Megafuse assemblies


<u>NOTE</u>: Find a suitable place, as close to the battery power source as possible, under the hood of the your vehicle to mount the completed Megafuse assemblies. Keep in mind that you have 12 feet of 6Ga. charging wire, and that the main power feed coming from your panel or bulkhead connection must also be able to reach the assembly.


1. Take the two Megafuse bodies and covers (items B) and snap them together. Remove the 4 nuts and lock washers from the studs on the fuse body assemblies.

2. Install the Megafuse jumper (item D above) over two of the studs on the Megafuse bodies. It is very important that the jumper MUST BE assembled on the side that is going to connect to your main power connection (starter solenoid or battery feed).

3. Notch top cover to clear jumper D as shown at right.

4. Snap one 175amp fuse (items C) onto the studs of each of the two Megafuse bodies (items B), over the jumper, then loosely re-attach the 4 nuts and lock washers back onto the assembled Megafuses. The fuse assemblies are ready to install into your vehicle. Page 2





# Building the 6Ga. charge wires and connecting them and the main panel power feed wire to the Megafuse assemblies:

<u>NOTE</u>: Make sure that your battery is disconnected! You will need to install the preassembled Megafuses from page 2 in your vehicle to start this part of the installation.

1. Pre-cut item F shrink tubing into (6) 1.00" - 1.25" pieces.

2. Take the 12-foot piece of 6Ga. red wire from this kit and route it from your starter (or other battery feed) over to the area where you have mounted your Megafuse and cut it to length. Strip the insulation on each end back 1/2". Install 2 pieces of shrink tubing F onto the wire. At the starter end, crimp and solder (1) of terminal G onto the wire. At the Megafuse end, crimp and solder (1) of terminal H onto the wire. Slide the shrink tubing over the terminals and heat it up to shrink it down.


3. Take the remaining portion of the 12-foot piece of 6Ga. red wire from this kit and route it from your alternator over to the area where you have mounted your Megafuse and cut it to length. Strip the insulation on each end back 1/2". Install 1 piece of shrink tubing F onto the wire. At the alternator end, slip on boot E as shown on page 3, then crimp and solder (1) of terminal J onto the wire. At the Megafuse end, crimp and solder (1) of terminal H onto the wire. Slide the shrink tubing over terminal H and heat it up to shrink it down.


4. Take the 10Ga. red main power feed wire from your engine or panel sub-kit and route it over to the area where you have mounted your Megafuse and cut it to length. Strip the insulation back 3/8". Install 1 piece of shrink tubing F onto the wire, then crimp and solder (1) of terminal K onto the wire.

5. Remove the 4 loosely tightened nuts and lock washers from the assembled Megafuses, then using the drawing on page 3 as a guide, install your pre-assembled wires from steps 2-4 above. Re-install the 4 nuts and lock washers onto the assembled Megafuses and tighten them down. This part of your installation is now complete.



Connection Kit Various Applications 92972153 instruction sheet rev 0.1 6/24/2019





Connect the Dimmer Switch wires as shown above.

- 1. The top center terminal of the Dimmer Switch is connected to the Headlight switch.
- 2. The terminal on the right side is connected to your headlight high beam terminal.
- 3. The terminal on the left side is connected to your headlight low beam terminal.

Connect the Dimmer Switch wires as shown above.

- 1. The top center terminal of the Dimmer Switch is connected to the Headlight switch.
- 2. The terminal on the right side is connected to your headlight high beam terminal.
- 3. The terminal on the left side is connected to your headlight low beam terminal.



www.americanautowire.com 856-933-0801

PART # 500042
DESCRIPTION:
DIMMER SWITCH
92964573 Rev 3.1 12/5/2014



www.americanautowire.com 856-933-0801

