


**American
Autowire**

www.americanautowire.com 856-933-0801


#	CIRCUIT	CIRCUIT RATING	FUNCTION	#	CIRCUIT	CIRCUIT RATING	FUNCTION
1.	ACCESSORY 1	30 amp fuse	Accessory power - spare	9.	PARK	15 amp fuse	Battery power for park lamps
2.	RADIO	20 amp fuse	Accessory power for radio	10.	BATTERY 2	20 amp fuse	Battery power - spare
3.	WIPER	15 amp fuse	Accessory power for wiper	11.	HORN SWITCH		Relay ground from horn switch
4.	HEAT/AC	30 amp fuse	Accessory for heat and A/C	12.	HORN OUT		Relay power to horn (Battery)
5.	HAZARD	20 amp fuse	12V feed for hazard switch (Battery)	13.	IGNITION 1	20 amp fuse	Ignition - spare
6.	TURN	20 amp fuse	12V feed for turn switch (Keyed)	14.	GAUGES	10 amp fuse	Ignition power for gauges
7.	BATTERY 1	20 amp fuse	Battery power - spare	15.	HEADLIGHTS	30 amp breaker	Battery power for headlight switch
8.	STOP/CTS Y	20 amp fuse	Battery power to brake switch				

USING THE SCREW DOWN CONNECTION BLOCKS


- 1** A screw driver is provided in this kit for use with our connection blocks. If you use any other screwdriver, please be sure that the tip is not wider than .150 inches.



- 2** Strip the wire to a length of 3/8". Use the strip gauge on the end blocks as a guide.



- 3** Note: The maximum wire size which can be installed into each cavity is one 12 gauge wire. Wires can be doubled in the cavity, but the maximum double is two 14 gauge wires.



- 4** Loosen the cavity set screw to the fully open position. Insert the wire into the open cavity (be sure that all of the wire strands are inserted in the cavity), and tighten the set screw as shown. As the set screw and clamp are steel, the threads will not strip. If you are using a power screw tool that has a torque setting, install to 30 inch pounds. For wire removal, loosen screw and remove wire.

