



1. Plug the wiper connector from branch 4 of the new dash/main harness (as shown on page 5 of the 92970164 instruction set) onto this new wiper switch assembly, then install the new switch and harness assembly into your dashboard using your original nut.
2. Attach your existing / original knob to the shaft and tighten the locking screw. **NOTE:** You will need to re-install your dash bezel prior to installing the existing / original knob.



**American  
Autowire**

www.americanautowire.com 856-933-0801

PART #

**510346**

DESCRIPTION:

Wiper Switch 1973-79 Ford  
Truck & 1978-79 Ford Bronco  
Classic Update Series

92970178 instruction sheet rev 1.0 2/27/2023



1. Plug the wiper connector from branch 4 of the new dash/main harness (as shown on page 5 of the 92970164 instruction set) onto this new wiper switch assembly, then install the new switch and harness assembly into your dashboard using your original nut.
2. Attach your existing / original knob to the shaft and tighten the locking screw. **NOTE:** You will need to re-install your dash bezel prior to installing the existing / original knob.



**American  
Autowire**

www.americanautowire.com 856-933-0801

PART #

**510346**

DESCRIPTION:

Wiper Switch 1973-79 Ford  
Truck & 1978-79 Ford Bronco  
Classic Update Series

92970178 instruction sheet rev 1.0 2/27/2023