


1968 - 1969 FUSE BLOCK BULKHEAD CONNECTOR
(viewed from interior side with fuse panel removed)



ENGINE HARNESS CONNECTOR
(viewed from fuse block bulkhead
connector side)

TACHOMETER WIRING INSTRUCTIONS

DASH SIDE

- A. CONNECT THE BLACK WIRE FROM THE TACH CONNECTOR TO A GOOD GROUND.
- B. PLUG THE PINK WIRE FROM THE TACH CONNECTOR TO AN IGNITION POWER TERMINAL ON THE FACE OF THE FUSE PANEL.
- C. CONNECT THE BROWN WIRE FROM THE TACH CONNECTOR TO FUSE BLOCK LOCATION A-X.

ENGINE SIDE

SELECT THE BROWN WIRE WITH A SPADE TERMINAL (U-SHAPED) AND A FLAT MALE TERMINAL.. CONNECT THE FLAT MALE TERMINAL TO LOCATION A-X ON THE ENGINE IGNITION HARNESS FUSE BLOCK CONNECTOR. CONNECT THE SPADE TERMINAL END TO THE DISTRIBUTOR SIDE (-) OF THE COIL.



**American
Autowire**

www.americanautowire.com 856-933-0801

PART #

CA6907

DESCRIPTION:

TACHOMETER KIT

1969 Camaro

X92963808 instruction sheet

Rev 3.0 11/16/2011