


-FUSIBLE LINK (BROWN)

DK BLUE
LT BLUE
LT GREEN
DK GREEN
TAN
BROWN


DK. BLUE
DK. GREEN
PINK
ORANGE
BROWN
WHITE







tooolo MADE MU.S.A. A another wiring product by				
INSTALLATION INSTRUCTIONS				
This wiring kit is designed for ease of installation. Please read the guidelines below, BEFORE STARTING your installation, to guarantee a successful job!				
STEP 1: <u>DISCONNECT YOUR BATTERY</u> : Disconnect the battery before installing the wiring kit to prevent any accidental shorting caused by loose bare wire ends.				
STEP 2: <u>MOUNT YOUR PANEL</u> : It is recommended that you mount your panel under the dash, in the kick panel, or under the front seat.				
STEP 3: <u>START INSTALLING KIT:</u> This kit is broken down into individual steps that are identified by a letter printed on the instruction sheets visible through each bag. These letters are the order of operation for installing y our kit. Start with the bag letter "A", then "B", etc. The order of installation is shown below.				
A500404Ignition Switch and Starter Wiring KitB500305Alternator Connection KitC500303Headlight / Accessory Switch KitD500302Steering Column / Turn Signal Connection KitE500353Gauge Connection Kit (Sending Unit Side)				
STEP 4: <u>RECONNECT YOUR BATTERY:</u> When you have completed the installation and are ready to reconnect the battery, make sure that the following electrical system grounds are in place:				
 A. Battery is grounded to the ENGINE BLOCK. B. Battery is grounded to the frame. C. Engine block is grounded to the frame. D. Body is grounded to the frame. 				
STEP 5: <u>CHECK ALL ELECTRICAL FUNCTIONS:</u> Any non-functioning items should be checked for proper installation. Any problems with your wiring and electrical circuit functions should be addressed to American Autowire Systems, Inc. as soon as possible to avoid any warranty problems.				
If you have any questions concerning this or any of our products, please feel free to call us at 1-800-482-WIRE.				
"AMERICAN AUTOWIRE MAKES IT EASY !!"				



Adjustable Fuel Warning Module Anti-Theft Relay Kit Brake Light switch Kit Brake Switch Brake Switch	p/n 500274 p/n 500239 p/n 500111 p/n 500097 p/n 500145	Sets Relay Relay Butto Butto
Brake Switch Brake Switch Courtesy Light Kit	p/n 500098 p/n 500240 p/n 500081	cor Leve Adjus Unde
Dual Relay Kit Fan Relay Kit (non Temp controlled) Fan Relay Kit (Temp controlled 212) Fan Relay Kit (Temp controlled 238) Headlight Connection Kit Neutral Safety switch (GM) Neutral Safety switch (Ford) Universal Relay Kit Voltage Reducer Module Wiper Switch	p/n 500338 p/n 500067 p/n 500084 p/n 500141 p/n 500113 p/n 500104 p/n 500140 p/n 500139 p/n 500142 p/n 500580 p/n 500146	lan Use f Com Com Spec GM 1 Ford Ford Use f Allow Two

a warning light or activates a relay at preset fuel level. ay control of starter circuit.

ay control of brake lights using hydraulic brake switches.

on type, 2 blade contact to operate brake lights

ton type, 4 blade contact to operate brake lights and cruise ontrol

er type, water resistant

ustable lever design, water resistant

ler dash lighting harness complete with mountable mp sockets

for any two heavy circuits, complete with mounting legs. nplete Kit wired with relay and fuse.

plete Kit wired with relay, fuse, and temperature sender. plete Kit wired with relay, fuse, and temperature sender. cial kit for difficult headlight mount applications.

TH400, TH350, 700R4.

C-4

C-6.

for any heavy duty application requiring a relay.

ws the use of 6 volt gauges when converting to 12 volts. speed switch for wiper.

