

NOTE: Please keep in mind that this is an upgraded switch, not an original replacement, and as such, the flat side on this switch may be in a different location than was your original. If you mount this new AAW switch in your dash and the flat side is in fact in a different location, the key may not line up as the original did. This will not alter the performance of the switch in any way. If you wish for your key to line up as it did in the OEM application, you will need to file out the flat spot in your original dash opening so that the switch can be rotated to the correct position. Once the backing nut C is set so that the depth of the switch will be secure and will not rotate.

INSTALLATION:

- NOTE: The instruction sheet packaged with this switch shows a copper lamp holder bracket. That bracket is not used in this application and it's installation can be ignored.
 - 1. Due to the nature of the chrome plating on threaded collar A, AAW recommends threading the nut on and off of the switch by hand a few times to clean up the threads before installing the switch into your dash.
 - 2. Plug in connector D from the dash wiring harness (bag G).
 - 3. Install the back-up nut C onto the switch. The depth of this nut will have to be determined when mounting the switch.
 - 4. Insert the switch into the hole in the dash panel.
 - 5. Install your original dash bezel plate.
 - 6. Slide on collar B.
 - 7. Screw on threaded collar A
 - 8. Insert your original or New AAW lock cylinder into the new switch to complete your installation.

<u>NOTE:</u> AAW has new lock cylinders with the correct GM style keys for your new 500684 ignition switch. Check below for your vehicle's correct application.



AAW P/N 500672 (with finger guard):

500423 - 1955-56 Chevy car 500434 - 1957 Chevy car 500481 - 1955-59 Chevy Truck 510217 - 1959-60 Chevy Impala 510063 - 1961-64 Chevy Impala 510267 - 1953-62 Chevy Corvette



AAW P/N 500674 (smooth face):

500467 - 1947-55 Chevy Truck 500560 - 1960-66 Chevy truck 510360 - 1965 Chevy Impala 510372 - 1966-68 Chevy Impala



www.americanautowire.com 856-933-0801

