

WARNING:

Validate the kit contents with the component list included on page 2 of this sheet before proceeding. This kit is intended to be used in a modified vehicle. Please read this sheet thoroughly and be sure that you understand everything explained on it prior to opening any of the enclosed packages, or before attempting to install any of the components. Once this kit has been opened or a component installed, the kit is not returnable.

- 1. This kit should typically be used in a **MODIFIED** application only.
- 2. This kit and all accessories that connect to this kit must be rated at 12 volts. The kit will not support 6 volt accessories.
- 3. This kit supports the use of aftermarket 12 volt heater and A/C systems.
- 4. This kit supports the use of a high current self-exciting 1-wire alternator or other style internally regulated alternators. An adapter may be necessary in some applications. The use of a stock, low amperage alternator is seriously discouraged as they cannot handle the higher current requirements of updated ignition systems, electric fans, aftermarket A/C systems, stereo systems, air ride suspensions, and other power hungry accessories and will ultimately create performance issues with the system.
- 5. This kit WILL NOT support the use of an ammeter. All AAW kits are engineered to supply the optimum charge to the battery. To achieve this performance, we route our 8ga. charge wire directly from the alternator output charge terminal to the starter battery termial. Due to the path of the charge being altered from the stock configuration, the gauge can no longer see a charge vs. a discharge, so it will not work properly. When ammeters were originally used, most generator or alternator current outputs were rated at a maximum of about 25-60 amps. Modified cars being built today typically utilize a 100 amp or higher output alternator. With these higher current units, ammeters, generally speaking, become a safety hazard. Ammeters are usually wired in parallel to the charging circuit, are typically unfused, and can short very easily causing a fire. A voltmeter is recommended as a good alternative.
- 6. This kit **IS NOT** set up with a resistance wire or ballast resistor for a standard points type ignition system. It is wired with a full 12 volt primary ignition feed that is hot in the run position. Primary ignition voltage in the starting position is handled via a full 12 volt bypass wire. Our system will support HEI, MSD, other electronic ignition systems, as well as most all computerized Fuel Injection systems. If you wish to run a points type system, there are extra parts (ballist resistor) that are not included in this kit will be required to complete that operation.





www.americanautowire.com 856-933-0801

92970053 instruction sheet Rev 0.1 12/12/2018

500703 - Highway 15 Wiring Kit

This kit contains the following components:

Part		
<u>Number</u>	<u>Description</u>	<u>Quantity</u>
500006	Ignition Switch	1
500042	Dimmer Switch	1
500257	Ignition Switch Adapter - GM Column	1
500302	Steering Column & Turn Signal kit	1
500303	Headlight Switch Connection kit	1
500332	Headlight Switch	1
500353	Gauge Connection kit	1
500354	Accessory Connection kit	1
500689	Mega Fuse kit	1
500699	Alternator Connection kit	1
500701	Highway 15 Series Panel	1
500718	Ignition Switch & Starter Connection kit	1
500919	Terminal Practice kit	1
92966047	Instruction Sheet	1
92970053	Warning and Contents Sheet	1
	Number 500006 500042 500257 500302 500303 500332 500353 500354 500689 500699 500699 500701 500718 500919 92966047	NumberDescription500006Ignition Switch500042Dimmer Switch500257Ignition Switch Adapter - GM Column500302Steering Column & Turn Signal kit500303Headlight Switch Connection kit500332Headlight Switch500353Gauge Connection kit500354Accessory Connection kit500689Mega Fuse kit500701Highway 15 Series Panel500718Ignition Switch & Starter Connection kit500919Terminal Practice kit92966047Instruction Sheet

Validate the kit contents with this component list. If there are any discrepencies with incorrect or missing parts, stop your installation and notify the supplier you purchased the kit from before proceeding.



www.americanautowire.com 856-933-0801

