



Mount the Heater switch in a 7/16 inch hole.

1. The "B" terminal is connected to a 12 volt fused ignition feed.
2. The other terminal is connected to the heater motor.



**American
Autowire**

www.americanautowire.com 856-933-9301

PART #

500144

DESCRIPTION:

HEATER SWITCH

92964640 instruction sheet Rev 3.0 8/26/2013