

**NOTE:** This circuit breaker should be mounted as close to the battery power source (junction block, starter relay, starter solenoid, etc.) as possible. AAW does NOT recommend installing this kit inside of the vehicle as the main power-feed from the battery source to the circuit breaker is an unfused lead, and as such, should not be routed to the inside of your vehicle.




**American  
Autowire**

www.americanautowire.com 856-933-0801

PART # **510598**

DESCRIPTION:  
Sealed Resettable Circuit Breaker  
Kit -200 amp

92971178 instruction sheet Rev 0.0 2/12/2015



**NOTE:** This circuit breaker should be mounted as close to the battery power source (junction block, starter relay, starter solenoid, etc.) as possible. AAW does NOT recommend installing this kit inside of the vehicle as the main power-feed from the battery source to the circuit breaker is an unfused lead, and as such, should not be routed to the inside of your vehicle.



**American  
Autowire**

www.americanautowire.com 856-933-0801

PART # **510598**

DESCRIPTION:  
Sealed Resettable Circuit Breaker  
Kit -200 amp

92971178 instruction sheet Rev 0.0 2/12/2015