


92973187


Starter Solenoid
(Not included
with this kit)




To "I" on starter solenoid

12V ignition
feed from
ignition switch
(Not included
with this kit)

Ignition
Coil




Distributor




To distributor
connector

Ballast Resistor
(Not included
with this kit)



To ignition switch side of resistor

To coil side of resistor



To ignition
coil



Tach



To pulse terminal on tach (if so equipped)

To 2 way
ignition
module
connector




This cavity is blank

To 4 way
ignition
module
connector



Ignition
Module
(Not included
with this kit)



**American
Autowire**

www.americanautowire.com 856-933-0801

Instructions for (NEW) Ford
Duraspark Ignition Harness

510824

92973187 instruction sheet rev 0.0 6/1/2020