

**NOTE:** If the fuse panel on your 510188 64-67 GTO kit ***DOES NOT*** have a sticker like the photo at the left, you have the first design harness and your instructions are listed below and follow this page.



Number	Description
500332	Headlight Switch
500674	Ignition Switch Lock Cyl. w/Keys
510707	Fuse, Relay, and Flasher kit
500708	Courtesy Light Connection kit
500709	Ignition Switch
500919	Practice Terminal Crimping Set
510190	Dash Harness kit
510191	Engine Wiring Kit
510192	Front Light Wiring kit
510194	Instrument Cluster Wiring kit
510193	Rear Body Wiring kit
510195	Console Wiring kit
510476	Alternator and main power Connection kit
500042	Floor Dimmer Switch
92967369	Firewall Mod. Template Sheet
92969480	Main Instruction Sheet
92969527	Warning Sheet



**American  
Autowire**

www.americanautowire.com 856-933-0801

1964-67 GTO  
First Design  
Instructions

92973181 rev. 0.0 4/28/2020