


WIRING INFORMATION FOR A STOCK 1955-56 CHEVY CLUSTER

INSTALLATION:

Terminals and connectors are provided for installation to a stock 1955-56 dash cluster. Pigtail connections are provided for the instrument lamps, oil lamp, and generator lamp. Connect the wire from this kit to the pigtails by splicing, soldering and applying shrink tubing protection. Refer to the diagram of the 1955-56 instrument cluster for additional circuit descriptions. Reference parts on SHEET 2.

Color Purpose Connection

- DARK BLUE** Right Hand Turn Lamp
Connect to the right hand turn signal indicator using lamp socket B and rivet C. Insert socket over the wire before the rivet.
- LIGHT BLUE** Left Hand Turn Lamp
Connect to the left hand turn signal indicator using lamp socket B and rivet C. Insert socket over the wire before the rivet.
- LIGHT GREEN** Hi-Beam Indicator
Connect to the hi-beam lamp using lamp socket B and rivet C. Insert socket over the wire before crimping the rivet.
- DARK GREEN** Temperature Gauge (-) sender
Use terminal J and connector K. See diagram.
This kit is designed to be used with an electric 1956 gauge. If using a stock 1955 gauge, discard this wire and use the capillary tube on your gauge. Otherwise, use a 1956 electric gauge.
- DARK BLUE** Oil Pressure Gauge
Connect to the oil indicator lamp pigtail (using lamp socket F) being sure to splice, solder and shrink tube the connection.
- TAN** Fuel Gauge
Connect this wire to the fuel gauge (-) sender location. 1955 fuel gauges will use terminal H and connector G. 1956 fuel gauges will use terminal J and connector K. See diagram.
- PINK** 12 Volt Ignition
Create an in line splice of 12 volt pink power leads as follows:
Connect one to the fuel gauge (+) 12 V location. 1955 fuel gauges will use terminal H and connector G. 1956 fuel gauges will use terminal J and connector K. See diagram.
Connect one to the temperature gauge (+) 12 V location using terminal J and connector K. See diagram. This kit is designed to be used with an electric 1956 gauge. If you are using a stock 1955 mechanical gauge, this wire will not be used.
Connect one to the pink wire on the oil lamp pigtail (splice, solder, and shrink tube this connection). See diagram. Be sure to solder and shrink tube the in line splice connection. See diagram.
- GRAY** Instrument Lamps
Create an in line splice of the instrument lamp pigtails which are provided (using terminal C and lamp socket B). Be sure to solder and shrink tube the connection. See diagram.
- BROWN/PINK** Gen / Alternator light
This pigtail assembly will be used if you are using the original generator lamp as an alternator lamp. Plug this pigtail into the (pigtail) connector with the brown and pink wires located on the dash harness next to the instrument cluster connectors.
- BLACK** Cluster Ground
Connect this wire to the back of your instrument cluster using terminal A. This is an additional ground lead that should not be necessary as the entire cluster housing is grounded through its mounting to the metal dash board housing.



Part Number	H
510409	
Description	INSTRUMENT CLUSTER CONNECTION KIT
92971250 instruction sheet Rev 1.0 1/25/2017	





GENERAL WIRING INFORMATION FOR ANY GAUGE CLUSTER

INSTALLATION:




The design of this harness allows for the installation of many different types of gauge clusters and special gauge packages in the 1955-56 Chevrolet. We have designed this kit so that any gauge cluster can be used by providing for a cluster disconnect in our under dash harness. Following are the wires and functions of those wires in the gauge cluster connection kit. Terminals and connectors are provided for installation to a stock 1955-56 dash cluster. However, the stock cluster does not use all the provided wires. See the overall schematic for a pictorial representation of the following circuit descriptions:

Color	Purpose	Connection
DARK BLUE	Right Hand Turn Lamp	Connect to the right hand turn signal indicator.
LIGHT BLUE	Left Hand Turn Lamp	Connect to the left hand turn signal indicator.
LIGHT GREEN	Hi-Beam Indicator	Connect to the hi-beam lamp.
DARK GREEN	Temperature	Connect to the temperature gauge (-) sender location.
DARK BLUE	Oil Pressure	Connect this wire to the oil pressure gauge (-) sender location.
TAN	Fuel Gauge	Connect this wire to the fuel gauge (-) sender location.
PINK	12 Volt Ignition	Create an in line splice of 12 volt pink power leads as follows: Connect one to the fuel gauge (+) 12 V location. Connect one to the temperature gauge (+) 12 V location. Connect one to the oil pressure gauge (+) 12 V location. Connect one to the voltmeter (+) 12 V location. Be sure to solder and shrink tube the in line splice connection. See diagram.
GRAY	Instrument Lamps	Create an in line splice to feed the gauge instrument lights
BROWN (pigtail)	Gen / Alternator light	This pigtail assembly will be used on stock 1955-56 instrument clusters. It may also be wired in if the cluster design you have created for your car includes the provision for a GEN /ALTERNATOR light. Plug this pigtail into the connector with the brown and pink wires located on the dash harness next to the instrument cluster connectors. Otherwise, the bulb socket pigtail will not be used and the mating connector should be taped back against the harness.
BLACK	Cluster Ground	Use this wire as a ground lead for individual gauges requiring separate grounds or any gauge control unit requiring a chassis ground.
WHITE	Tachometer	Connect this wire to the sender lead of your tachometer. This wire is supplied loose piece and must be plugged into the mating cluster connector so as to maintain color continuity with its mating connector.

PURPLE / YELLOW WIRES: SEE SHEET 5



sheet 2



www.americanautowire.com 856-933-0801

Part Number

510409

H

Description

INSTRUMENT CLUSTER CONNECTION KIT

92971250 instruction sheet Rev 1.0 1/25/2017


INSTALLATION OF GAUGE WIRING USING THE STOCK 1957 INSTRUMENT CLUSTER

INSTALLATION:

Terminals and connectors are provided for installation to a stock 1957 dash cluster. Pigtail connections are provided for the instrument lamps, oil lamp, and generator lamp. Connect the wire from this kit to the pigtails by splicing, soldering and applying shrink tubing protection. Refer to the diagram of the 1957 instrument cluster for additional circuit descriptions. Reference parts are on SHEET 4.

Color Purpose Connection

- DARK BLUE** Right Hand Turn Lamp
Connect to the right hand turn signal indicator using lamp socket B and rivet C. Insert socket over the wire before the rivet.
- LIGHT BLUE** Left Hand Turn Lamp
Connect to the left hand turn signal indicator using lamp socket B and rivet C. Insert socket over the wire before the rivet.
- LIGHT GREEN** Hi-Beam Indicator
Connect to the hi-beam lamp using lamp socket B and rivet C. Insert socket over the wire before crimping the rivet.
- DARK GREEN** Temperature
Connect to the temperature gauge (-) sender location using terminal H and connector G. See diagram.
- DARK BLUE** Oil Pressure
Connect to the oil indicator lamp pigtail (using lamp socket assembly F) being sure to splice, solder and shrink tube the connection.
- PINK** 12 Volt Ignition
Create an in line splice of 12 volt pink power leads as follows:
Connect one to the pink wire on the oil lamp pigtail (splice, solder, and shrink tube this connection). See diagram.
Connect one to the fuel gauge (+) 12 V location using terminals H and connector G.
Connect one to the temperature gauge (+) 12V location using terminals H and connector G. See diagram. Be sure to solder and shrink tube the in line splice connection.
- TAN** Fuel Gauge
Connect this wire to the fuel gauge (-) sender location. Use terminal H and connector G.
- GRAY** Instrument Lamps
Create an in line splice of the instrument lamp pigtails which are provided (using lamp socket B). Be sure to install socket before splicing wires. Be sure to solder and shrink tube the connection. See diagram.
- BROWN** Gen / Alternator light
This pigtail assembly will be used if you are using the original generator lamp as an alternator lamp. Plug this pigtail into the (pigtail) connector with the pink and brown wires located on the dash harness next to the instrument cluster connectors.
- BLACK** Cluster Ground
Connect this wire to the back of your instrument cluster using terminal A. This is an additional ground lead that should not be necessary as the entire cluster housing is grounded through its mounting to the metal dash board housing.



Part Number

510409

H

Description

INSTRUMENT CLUSTER CONNECTION KIT

92971250 instruction sheet Rev 1.0 1/25/2017



American Autowire

www.americanautowire.com 856-933-0801

INSTALLATION:

GENERAL WIRING INFORMATION FOR ANY GAUGE CLUSTER

The design of this harness allows for the installation of many different types of gauge clusters and special gauge packages in the 1955-56 Chevrolet. We have designed this kit so that any gauge cluster can be used, by providing a gauge disconnect feature. Following are the wires and functions of those wires in the gauge cluster connection kit. Terminals and connectors are provided for installation to a stock 1955-56 dash cluster. However, the stock cluster does not use all the provided wires. Wire instrument cluster, then simply plug into the dash harness. See the overall schematic for a pictorial representation of the following circuit descriptions:

Color	Purpose
DARK BLUE	Right Hand Turn Lamp
LIGHT BLUE	Left Hand Turn Lamp
LIGHT GREEN	Hi-Beam Indicator
DARK GREEN	Temperature Gauge (-) sender location.
DARK BLUE	Oil Pressure Gauge (-) sender location.
TAN	Fuel Gauge (-) sender location.
PINK	12 Volt Ignition

Create a splice of 12 volt pink power leads as follows:

- Connect one to the fuel gauge (+) 12 V location.
- Connect one to the temp gauge (+) 12 V location.
- Connect one to the oil gauge (+) 12 V location
- Connect one to the voltmeter (+) 12 V location.

Be sure to solder and shrink tube splice connections.

GRAY Instrument Lamps

Create an splice to feed the gauge instrument lights

BLACK Cluster Ground

Use this wire as a ground lead for individual gauges requiring separate grounds or any gauge control unit requiring a chassis ground.

WHITE Tachometer

Connect this wire to the sender lead of your tachometer. This wire is supplied loose piece and when using a tachometer must be plugged into the mating cluster connector so as to maintain color continuity with its mating connector.




BROWN & PINK Gen / Alternator light

This pigtail assembly will be used on stock 1955-56 instrument clusters. It may also be wired in if the cluster design you have (pigtail) created for your car includes the provision for a GEN /ALTERNATOR light. Plug this pigtail into the connector with the pink and brown wires located on the dash harness next to the instrument cluster connectors. Otherwise, the bulb socket pigtail will not be used and the mating connector should be taped back against the harness.

PURPLE / YELLOW WIRES: SEE SHEET 5



www.americanautowire.com 856-933-0801




Part Number	H
510409	
Description	INSTRUMENT CLUSTER CONNECTION KIT
92971250 instruction sheet Rev 1.0 1/25/2017	

TYPICAL ELECTRIC SPEEDO CONNECTIONS

Below are some general instructions for hooking up an electric speedometer. This connector and these instructions will ONLY be used in the event that you are utilizing an aftermarket electric speedometer. If your car does NOT have an electric speedometer, this connection will NOT be used and should not be plugged onto your dash harness. It is best to consult the speedometer manufacturer's instructions if you have any questions.

<u>Yellow</u>	VSS Ground	Connect to VSS "-" on speedometer.
<u>Purple</u>	VSS Pulse	Connect to VSS input on speedometer.
<u>Purple/White</u>	VSS Power	Connect to 12V power on speedometer.
<u>Black/White</u>	Speedo Ground	Connect to ground on speedometer.
<u>Pink/White</u>	Speedo Power	Connect to 12v power on speedometer. NOTE: This wire will double onto the same stud as the purple/white VSS power wire from above.



CONNECTOR C

All connectors are depicted looking into the open end of the connectors, **NOT** wire entry end



**American
Autowire**

www.americanautowire.com 856-933-0801

Part Number	510409	H
Description		
INSTRUMENT CLUSTER CONNECTION KIT		
92971250 instruction sheet Rev 1.0 1/25/2017		

THIS PAGE INTENTIONALLY
LEFT BLANK



www.americanautowire.com 856-933-0801

Part Number	510409	H
Description	INSTRUMENT CLUSTER CONNECTION KIT	
92971250 instruction sheet Rev 1.0 1/25/2017		